Gas Chassis RV Maintenance Schedule Program

Months/miles Pre travel	3k	6k	9k	12k	15k	18k	21k	24k	27k	30k	33k	36k	39k	42k	45k	48k	51k	54k	57k	60k	63k	66k	69k	72k	75k	78k	81k	84k	87k	90k	93k	96k	100k
1 Auto park brake insp.	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√
2 Check lines, hoses and fluids	√		√		√		√		√		√		√		√		√		√		√		√		√		√		√		√		√
3 Check F and R shocks	√		√		√		√		√		√		√		√		√		√		√		√		√		√		√		√		√
4 Check Tire PSI/Air bags				√			√			√			√			√			√			√			√			√			√		
5 Check engine oil	√			√			√			√			√			√			√			√			√			√			√		
6 Inspect belts	√									√										√										√			
7 Check all exterior lights	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√
8 Change engine oil and filter	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√
9 Inspect & lubricate chassis components	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√
10 Check/change axle fluid	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√	√
11 Inspect exhaust system	√		√		√		√		√	√		√	√		√		√	√			√						√						
12 Rotate tires		√		√		√		√						√		√				√		√		√		√		√		√		√	
13 Inspect & lubricate brake system				√				√				√				√				√								√				√	
14 Check F a& R U bolt torque and stabilizers				√				√																									
15 Clean & pressure check radiator cap				√				√				√				√				√				√				√					
16 F wheel bearing adj. & lubrication					√										√					√					√				√				
17 Inspect shields & under hood insulation					√										√					√					√				√				
18 Check/change air cleaner					√										√					√					√				√				
19 Change fuel filter								√								√								√							√		
20 Brake fluid change								√								√								√							√		
21 GM Hydromatic Trans.																																	√
22 Allison Trans.				√																													
23 Inspect fueld tank, cap, & lines																				√													
24 Evap control emissions insp.																				√													
25 Check all wheel nuts for torque		√				√		√						√		√				√		√		√		√		√		√		√	
26 Inspect spark plug wires													√																				√
27 Replace spark plugs																																	√
28 Check positive crankcase ventilation																																	√